

KNEAL KNEE CRUISER SET UP

INSTALLING THE HANDLEPOST



WHAT YOU WILL NEED

6MM Hex Wrench (supplied) and a little elbow grease (not supplied).

- 1 Remove scooter from box (may require scissors or a box knife).
- 2 Insert handlepost. Be sure that is fully seated. If necessary, pinch the wedge against the handlepost (see image B and C).
- 3 Release the handlepost exposing the handlepost anchor (see image D).
- 4 Using the 6mm hex wrench, turn the anchor bolt approximately 1/4 turn clockwise. (see image D). Do not turn the bolt counterclockwise more than a single turn.
- 5 Return the handlepost to its original upright position and align handlebars (see image E). Insure that the handlebars are parallel to the front crossmember. Also note that when the bars are properly aligned the release handle will be slightly off center.
- 6 Once again, release the handlepost exposing the handlepost anchor bolt (see image D).
- 7 Using the 6mm hex wrench, turn the anchor bolt clockwise until tight (see image D). Do not turn the bolt counterclockwise more than a single turn.
- 8 Return the handlepost to the upright position, Check alignment (see image E).

NOTE: READ YOUR USER'S MANUAL

